

Cigarette Lighter

Mains Operated Safety Lighter

Many fires, deliberate or accidental, are caused by misuse of cigarette lighters.

The solution is to prohibit the use of lighters, and to provide a fixed, safe cigarette lighting appliance, and so eliminate the risk.



Operation is simple:

Press the 'Start' button on the front of the unit.

The 'Wait' lamp on the front of the unit will flash, with increasing speed while heating and then the 'Ready' lamp will light. The element is then ready to light the cigarette.

The amber 'Wait' lamp will then light for up to 1 minute to allow the unit to cool.

Once the 'Wait' lamp is out the unit is ready to be re-used.

- **No flame**
- **Microprocessor controlled**
- **Robust stainless steel construction**
- **Simple one-button operation**
- **Rapid heating time**
- **Status indication lamps**
- **Replaceable element**
- **Safety thermal cut-out**
- **Mains powered**

Mains supply

220/240 volts AC 120VA max.

This appliance must be earthed.

Size

200w x 180h x 60d

Cable Entry

The unit is designed to be installed as a fixed installation, the cable entry is at the bottom left of the unit.

Mounting Details

Mounting height should be 1450mm from floor to the bottom of unit. The unit is secured to the wall with 4 fixings, and is hinged at the bottom for service access. The power will automatically turn off if the front cover is opened.

Service

The unit can be opened by a trained, responsible person to service the unit and replace/clean the element.

Only heating elements supplied by PSS should be used.

To remove the element, open the enclosure. Once the element is cool, remove by pushing the plastic handle toward the front of the unit and lifting the element out.

Warning: this unit will be very hot if recently used.

Peripheral Support Services Ltd

13-14 Enterprise Court, Rankine Road, Basingstoke, Hampshire RG24 8GE England

t: +44 (0)1256 844685 f: +44 (0)1256 810082 e: sales@pss-firequest.co.uk

w: www.pss-firequest.co.uk



Assessed to ISO 9001
BREG Ref No: 888